



CONSTRUCTION NOTES:

- ① VERIFY ALL DIMENSIONS PRIOR TO POURING BASE SLAB.
- ② EXERCISE CARE TO MAINTAIN AND TO PROVIDE A LEVEL SURFACE UNDER WALLS.
- ③ FOR ALL WALLS, BROOM OR ROUGHEN FINISH SLAB 15" EACH SIDE OF WALL CENTERLINE.
- ④ CONTRACTOR TO BEND OR CUT DOWELS UNDER WALLS BEFORE POURING BASE SLAB.
- ⑤ REBAR AND TO BE TIED TO MAT. DOWELS ARE BENT AS REQUIRED WHEN FILLETS ARE POURED BY PECCO.
- ⑥ REBAR, AND PROVIDED AND INSTALLED BY PECCO.

DESIGN NOTES:

- ⑦ BASE SLAB & EQUIPMENT SLAB DESIGN BY ENGINEER
- ⑧ WALL SUPPORT DOWEL SYSTEM DESIGN BY PECCO.
- ⑨ WALL WEIGHT IS 1,500 LB/LINEAR FOOT, APPROXIMATE.

TYP. BASE SLAB DETAILS
150,000 G.P.D.

PECCO DWG NO:			
SCALE: N.T.S.			
DATE: 10/05/07			
DWN BY: L.C.G.			
APPROVED:			
NO	DATE	REVISION	

PECCO

PROCESS ENGINEERED EQUIPMENT CO.
438 MCBRIDE LANE
P.O. BOX 9549
CORPUS CHRISTI, TEXAS. 78469
361-289-8891